



Metlam Australia
Care & Maintenance Guide
Signage

Cleaning and Maintaining Signage



Metlam Australia signage should be subjected to a regular, controlled cleaning regime as described below. Metlam Australia takes no responsibility for any damage to walls or fixtures due to incorrect cleaning or the use of incorrect cleaning materials.

(1) Guidelines for day-to-day upkeep

Using a clean damp soft cloth:

1. Dip the cloth in clean warm soft water – wring dry
2. Carefully wipe the sign, taking care not to rub away any of the braille lettering
3. Wipe the sign with a dry cloth to remove excess water, again taking care
4. Ensure your cloth is cleaned between uses

 Do not use abrasive cleaners or drag rough items across the surface and be aware of grit trapped under other materials. This can cause scratches.

(2) Repairing wear and tear

In cases where signs show extreme symptoms of wear and tear, a non-abrasive, noncorrosive commercial cleaning spray such as Mr Sheen can be used with care, although we do not recommend this is used on every occasion.



For more information on how to clean and maintain your Metlam Australia products visit the Metlam Australia YouTube channel [here](#)