

For your convenience, Metlam Australia Moda Hinges come pre-tensioned to a standard use setting. We recommend against further tensioning before testing the standard tension setting after installation. Should you require, further tensioning, our Moda Spring Hinge offers additional adjustment levels.

You will need:

- a. 2mm Allen / Hex key to release the grub screw.
- b. 6mm Allen / Hex key to re-tension the spring settings.

Steps:

1. Use the 2mm Allen / Hex key to release the grub screw at the rear of the hinge as shown below.



2. Use the 6mm Allen / Hex key to adjust the bolt on the underneath side of the hinge barrel as shown below.



Note: There are 6 adjustment settings available as shown.



Left hand hinges:

- Hold closed increase tension: Turn the bolt on the underneath side of the hinge barrel **anti-clockwise at ¼ turn increments**. Find the locator hole and re-tighten the grub screw while holding the hinge in place.
- Hold closed decrease tension: Turn the bolt on the underneath side of the hinge barrel **clockwise at ¼ turn increments**. Find the locator hole and re-tighten the grub screw while holding the hinge in place.
- Hold open increase tension: Turn the bolt on the underneath side of the hinge barrel **clockwise at ¼ turn increments**. Find the locator hole and re-tighten the grub screw while holding the hinge in place.
- Hold open decrease tension: Turn the bolt on the underneath side of the hinge barrel **anti-clockwise at ¼ turn increments**. Find the locator hole and re-tighten the grub screw while holding the hinge in place.

Right hand hinges:

- Hold closed increase tension: Turn the bolt on the underneath side of the hinge barrel **clockwise at ¼ turn increments**. Find the locator hole and re-tighten the grub screw while holding the hinge in place.
- Hold closed decrease tension: Turn the bolt on the underneath side of the hinge barrel **anti-clockwise at ¼ turn increments**. Find the locator hole and re-tighten the grub screw while holding the hinge in place.
- Hold open increase tension: Turn the bolt on the underneath side of the hinge barrel **anti-clockwise at ¼ turn increments**. Find the locator hole and re-tighten the grub screw while holding the hinge in place.
- Hold open decrease tension: Turn the bolt on the underneath side of the hinge barrel **clockwise at ¼ turn increments**. Find the locator hole and re-tighten the grub screw while holding the hinge in place.