

ML640AS_N Recessed Horizontal Soap Dispenser

Note

This product is to be installed by suitably qualified persons, in a fit-for-purpose application, to suitable materials, using suitable fixings, and complying with any relevant codes.

Dimensions

- **Overall Size:** 150mmW x 260mmH x 159mmD
- **Wall Opening:** 125mmW x 235mmH x 105mmD

Hardware Provided

- 2x Button Head Screws
- 2x Washers
- 2x Wall Plugs
- 1x Key (Spare keys can be ordered using the part number E114_KEY)


Before Installation

- Inspect the product. If there is any damage or missing parts, do not install the product and contact your place of purchase.
- Be aware of any pipes/wires that may be inside the wall.
- Ensure the wall is plumb/flat without any raised surfaces.
- Check that there will be adequate clearance for the front face of the unit to be removed once installed.

Installation Instructions

Placement may be subject to regulations/codes and architectural drawings. Correct positioning is the responsibility of the installer

1. Create a rough wall opening 125mmWide x 235mmHigh.
Noggins will need to be installed in the wall above and below the opening.
2. Unlock the soap dispenser with the key provided and pull the front face panel and reservoir out to locate the mounting holes.
3. Mark the mounting holes located at the top and base of the recess box on the noggins, checking that all sides are level.



4. Using the button head screws and washers provided, fasten the recess box to the noggins through the mounting holes located at the top and base of the recess box. Be mindful that the slot for the locking mechanism is located at the top.
5. Apply neutral cure silicone to all edges where the recess box meets the wall and around the screws/washers.
6. Insert the front face panel and reservoir into the recess box and lock the soap dispenser.
7. Retain the key for the end user.



This product is AS1428.1 compliant (accessible compliant) when installed in accordance with the guidelines.

The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.

The photographs and line drawings of the products presented above are representational only.
Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions.