# **Installation Guidelines Sheet**



# ML921 & ML924 Waste Receptacles

## **Material Specifications**

- #304 Stainless Steel
- Top & bottom edges hemmed for safety

#### Mounting

Wall Mount Visible Fix

### **Dimensions / Capacity**

- ML921: 358mmW x 433mmH x 155mmD / 23 Ltr
- ML924: 381mmW x 508mmH x 230mmD / 45 Ltr

#### **Installation Guidelines**

- May be subject to Australian Building Code Regulations for height and location fixing and may be subject to placement as per architectural drawings. In all cases, this is the responsibility of the installer.
- 1. Using the mounting hole dimensions on the unit to measure and mark placement for the unit.
- 2. Using appropriate fixings, fit unit to the wall and loosely secure.
- 3. Check the unit is level and tighten fixings to finish installation.

The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.



\*ML920, ML921 & ML924

The photographs and line drawings of the products presented above are representational only. Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions.