

METLAM AUSTRALIA POWDER COATED STAINLESS STEEL PRODUCT CARE AND MAINTENANCE GUIDE

For everyday cleaning, wipe the surface with a damp soft cloth or sponge. You may also use a mixture of warm water and mild Neutral pH soap or detergent (such as PZ Cussons Morning Fresh).

After cleaning, wipe the surface dry with a soft absorbent cloth.

Please note, powder coating is not impervious to harsh solvents and many commercial cleaning solutions will damage the finish. High pressure cleaning is not recommended as this may also compromise the quality of the product.

AVOID SCRATCHES

Powder Coated Stainless Steel can be scratched by careless handling or aggressive scrubbing. Avoid dragging rough items across the surface and be aware that grit, trapped under other materials, can actually cause surface scratches.

CHEMICAL REACTION

If left in contact with salts or acids for extended periods, Metlam Australia Powder Coated Stainless Steel products may be compromised. Applying a regular maintenance/cleaning schedule will minimise any potential problems.

Using incorrect cleaning products can damage your Metlam Australia Powder Coated Stainless Steel product and void the warranty.

AVOID:

- Rubbing with steel wool (wire wool) or scraping with steel tools
- Using scourers and cleaning cloths that have been used on ordinary steel
- Rubbing plastic scourers across the grain of brushed surfaces
- Using concentrated bleach or hydrochloric acid-based cleaning products
- Contact with products containing chlorine bleach, hydrochloric or muriatic acid

The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any commercial washroom product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.

The photographs and line drawings of the products presented above are representational only.

Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions