



Metlam Australia Care & Maintenance Guide Toilet Partition Hardware

Metlam Australia Pty Ltd

PH: 1300 METLAM

E:sales@metlam.com.au



Cleaning and Maintaining Toilet Partition Hardware



Metlam Australia's Toilet Partition Hardware (TPH), such as lock and indicators, hinges, hooks and handles, benefit from regular cleaning and maintenance.

Cleaning TPH

- **1. Inspect regularly:** Inspect the TPH to ascertain condition and maintenance requirements. Applying regular hygiene measures, like a maintenance/cleaning schedule, will minimise any potential problems.
- **2. Prepare your cleaning materials:** You'll need a clean dry cloth, a clean damp cloth or sponge, and a soft absorbent cloth.
- **3. Wipe the TPH:** Start by wiping the TPH with a dry cloth to remove loose dirt and debris. This will prepare the surface for cleaning.
- **4. Clean the TPH:** Gently wipe the TPH with the damp cloth or sponge, paying attention to areas where marks may be present.
- **5. Rinse and dry:** Once the TPH is clean, use a soft absorbent cloth to dry the grab rail completely to ensure that streaky marks aren't left behind.

Maintaining Hinges

To ensure the longevity of your hinges, a 12-monthly maintenance regime is recommended. Metlam Australia hinges come with lift-off capability so you can remove the door from the hinge with ease. After the door has been removed:

1. Wipe down the hinge barrel with a clean cloth or paper towel to remove grime and dust buildup.

2.Lightly spray the hinge pin with a silicone spray remembering to wipe off any excess spray from the hinge and door.

3.Return the door to the cubicle frame by reinserting the hinge pin into the barrel.

The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any stainless-steel product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.



Is the lock jammed?

First, check there is not a foreign object inserted into the lock or that the tongue is not bent due to vandalism or misuse.

Use a silicone spray to loosen the tongue of the lock and work the silicone into the lock by opening and closing.

▲ Before cleaning with a new cleaning product, it is recommended that a small non-visible area of the seat be tested to ensure that no colour change of damage will occur.

O not drag rough items across the surface and be aware of grit trapped under other materials. This will spoil the finish and can cause scratches.

O not rub with steel/wire wool or a metal brush or scrape with steel tools. This can scratch the surface.

Do not use cleaning products containing chlorine bleach, hydrochloric, or muriatic acid. This can damage the surface.

Using incorrect cleaning products/methods can damage your Metlam Australia Toilet Partition Hardware (TPH) and void the Metlam Australia Warranty.



For more information on how to clean and maintain your Metlam Australia products visit the Metlam Australia YouTube channel **here**

The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any stainless-steel product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.