Installation Guidelines Sheet



78

SMR327P SMR332P Series Straight Grab Rails

Material Specifications

- 32mmØ #304 Stainless Steel Grab Rail
- #304 Stainless Steel Concealed Mounting Flanges
- 78mmØ Twist Lock Flange Covers
- Mounting Flanges Welded to Grab Rail for Maximum Strength

Dimensions

SMR327P: 300mm C to C SMR330P: 450mm C to C SMR331P: 600mm C to C SMR332P: 750mm C to C

Mounting

Concealed Fix - 78mmØ Mount

Installation Guidelines

- May be subject to Australian Building Code Regulations for height and location fixing and may be subject to placement as per architectural drawings. In all cases, this is the responsibility of the installer.
- Fixings and anchors are not included with the units and are the responsibility of the installer to appropriately fix the unit to the wall.
- **1.** Locate fixing position on wall or partition and mark using mounting holes, ensuring the unit is level.
- **2.** Mount the concealed mounting flanges to the wall using appropriate fixings (not supplied).
- **3.** Slide covers over mounting flanges, ensuring the raised edges of the flange lines up with the dimples of the flange cover. Twist and lock into place.
- 4. Check the unit is level to finish installation.

Safety Warning

 Ensure that there is proper structure support within the wall. Grab rails are no stronger than the anchors and walls to which they are attached. Grab rails must be firmly secured in order to support the loads for which they are intended.

NOTE: The materials and construction of this grab rail meets AS1428.1 force requirements to be able to withstand a force of 1100Nm.



This product is AS1428.1 compliant (accessible compliant) when installed in accordance with the guidelines.

The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson The and services maintained by knowledgeable initionial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to Metlaforesst instellation according and the staff of the food under the competent in design and dimensions.

Metlam Australia Pty Ltd T: 1300 METLAM E: sales@metlam.com.au www.metlam.com.au



The photographs and line drawings of the products presented above are representational only. Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions.