



Metlam Australia Care & Maintenance Guide Baby Change Stations

Cleaning and Maintaining Baby Change Stations

Cleaning and maintaining your baby change stations regularly is essential to maintain a safe environment for children and their carers.

Maintaining a clean and functional baby change station is just a matter of a few simple steps.

1.Regular inspection: Inspect the baby change station to ascertain condition and maintenance requirements. Applying regular hygiene measures, like a maintenance/cleaning schedule, will minimise any potential problems.

- Check that the baby change station opens and closes smoothly.
- Ensure the hardware is tight and that the baby change station is properly secured to the wall.
- Ensure that the baby change station has both ends of a non-frayed strap and that the buckle clicks closed.
- Check that any bed liner dispensers are well-stocked.
- Check that both the interior and exterior surfaces aren't damaged.

***Immediately take the unit out of service if any component is missing or damaged.**

2.Prepare your cleaning materials: You'll need a clean damp cloth/sponge or soft brush, mild neutral pH soap or detergent, a disinfectant, and warm soft water, along with any personal protective equipment (PPE) you may require.

3.Wipe the baby change station: Start by rinsing the baby change station with warm water to remove loose dirt and debris. This will prepare the surface for cleaning.




4.Clean the baby change station: Gently wipe the baby change station with the soapy cloth/sponge or soft brush, paying attention to areas where marks may be present.

*On stainless steel exterior models, follow the direction of the grain for best results and avoid using excessive amounts of liquid near the edges.

5.Rinse and dry: Once the baby change station is clean, rinse it thoroughly with clean water to remove any soap residue. Use a soft absorbent cloth to dry the baby change station completely to ensure that streaky marks aren't left behind.

6.Disinfect the change area: Use a ready-to-use disinfectant wipe product or apply a disinfection solution to a cloth then wipe over the change area.

All disinfectant cleaning products need to be applied for the specified contact time, as per the manufacturer's instructions.

-  Do not use abrasive cleaners or drag rough items across the surface and be aware of grit trapped under other materials. This will spoil the finish and can cause scratches.
-  Do not put hot objects directly on the surface. Prolonged exposure to high temperatures may damage the surface.
-  Do not rub with steel/wire wool or a metal brush or scrape with steel tools. This can scratch the surface.

Using incorrect cleaning products/methods can damage your Metlam Australia Baby Change Station and void the Metlam Australia Warranty.



For more information on how to clean and maintain your Metlam Australia products visit the Metlam Australia YouTube channel [here](#)