

## ML781 Series Stainless Steel Lockable Medicine Cabinet & Mirror

### Material Specifications

- #304 Stainless Steel
- 5mm Safety Glass (Vinyl Backed)

### Dimensions

- **Mirror Size:** 775mmH x 435mmW
- **ML781\_REC Recessed:** 800mmH x 435mmW x 110mmD
- **Wall Opening:** 735mmH x 410mmW x 90mmD (minimum)
- **ML781\_SM Surface Mounted:** 800mmH x 435mmW x 110mmD x 115mm Projection

### Mounting Points

- **Rear:** 50mm in from left/right, 105mm up/down from edges
- **Side:** 60mm in from rear of internal fascia, 105mm up/down from edges

### Installation Guidelines

- *May be subject to Australian Building Code Regulations for height and location fixing and may be subject to placement as per architectural drawings. In all cases, this is the responsibility of the installer.*
- *It is recommended that the unit is installed whereby it clears any other fixtures by at least 200mm.*

1. Locate height requirement and mark on wall.
  - For Recessed Unit – ensure that there are no internal services fittings or fixtures present, such as electrical or plumbing before cutting out the cavity for the unit. Mount battens to internal cavity section to secure the unit to, then drill fixing holes using mounting point holes.
2. Secure the unit to the wall or cavity with appropriate screws and wall plugs.
  - It is recommended that these units be securely fixed to the substrate (e.g. noggins) or that suitable fasteners or anchors are used to securely affix the unit to the plasterboard, concrete or brick wall.
3. Check opening and closing mechanism to finish installation.

### Features

- Lockable (tumbler lock located on centre edge on mirror fascia).
- 5 x 90mmD x 385mmW shelves (including base) – 4 are removable/adjustable.
- Shelves can be inverted to provide a protective lip option.
- Universal Left Hand or Right-Hand door opening.



This product is AS1428.1 compliant (accessible compliant) when installed in accordance with the guidelines.

*The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.*

The photographs and line drawings of the products presented above are representational only.  
Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions.