

MATERIAL SPECIFICATION & INSTALLATION GUIDE

PRODUCT ITEM CODE & DESCRIPTION

ML 021 ~ ANTI THEFT SPINDLE FOR STANDARD TOILET ROLL HOLDERS



MATERIAL SPECIFICATION / FEATURES:

Hi Density ABS Body – Matt Black Finish / most standard Toilet Paper and some “mini jumbo” Toilet Paper Roll Holders will fit internally, converting the toilet paper dispenser/fixture into being tamperproof re theft of toilet paper

DIMENSIONS:

110~130mm Adjustable Width x 35mmØ (holes either end for roller are 25mmØ)

INSTALLATION:

1. Remove toilet roll holder from dispenser, unscrew/disassemble Spindle
2. Insert Toilet Roll Holder from dispenser into Spindle, compress slightly and re-assemble Spindle
3. Adjust width to suit particular Toilet Roll Holder/Dispenser and/or paper, so as ends of Spindle position with approximately 1~2mm clearance either end in the dispenser, allowing Spindle/roller unit to rotate

NOTE: To ensure Spindle remains at set width for dispenser, it is recommended that either Loctite® or similar is applied to thread when determining actual width

4. Remove by putting finger in side slots, compress roller and remove Spindle
5. Position toilet roll onto Spindle and reinstate into dispenser
6. To remove/replace toilet paper, tear core off Spindle and follow point 4. above

These units should only be installed by a competent tradesperson and Metlam Australia takes no responsibility for any damage to walls or fixtures due to incorrect installation.